

WARNING

IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

This is not a safety device


DO NOT LEAVE CHILDREN UNATTENDED EVEN WHEN HARNESS IS USED


- Follow the manufacturer's instructions
- The harness must always be used and correctly fitted - most injuries from high chairs are caused by falls
- Ensure to use the high chair on a flat, even and horizontal floor and not elevate the high chair on any structure or table
- Always use the restraint system
- Falling hazard: Prevent your child from climbing on the product
- Be aware there is risk of tilting when a child can push its feet against a table or any other structure
- Keep children away when unfolding and folding the product to avoid injury
- leg connections should be inspected and tightened regularly
- The product is intended for children able to sit unaided and up to 3 years or maximum weight of 15Kg
- Incorrect installation may result in instability & weakness
- Keep plastic bags away from children
- To prevent falls, position the highchair away from solid structures
- Keep away from all dangerous items such as heat sources, liquids, window coverings, cords etc.
- ONLY use for children who are able to sit unaided
- Do not use the high chair unless all components are correctly fitted & adjusted. Check frequently
- Be aware the risk of open fire & other sources of strong heat, in the vicinity of the high chair
- Do not use the high chair if any parts are broken, torn or missing
- Always keep the tray assembled on the high chair

THE MAX WEIGHT OF THE CHILD SHOULD NOT EXCEED 15KGS


Feeding Chair

Assembly Guide






1.




Warranty Registration - Register
Your TikkTakk Product Online

Here's what you need:


- Receipt
- Date of Purchase
(on your receipt)



1.



2.




2.




leg connections should be inspected and tightened regularly

Extension Legs

Assembly Guide



*Extension legs not included with Feeding Chair
RYFC81



PRODUCT NOTICE

MOST INJURIES RELATED TO HIGH CHAIRS ARE CAUSED BY FALLS.

- Incidents of injuries related to the use of high chairs are substantially higher than most other products
- Assemble all components only according to TikkTokk's guidelines herein
- If harness is provided, ensure it is correctly fitted
- This high chair is made of varnished wood, as such, liquids including water, oil, wet food & drinks will damage the surface
- Wipe only with a dry or slightly damp cloth