

WPC Outdoor Bench Set

Assembly Guide

WARNING



- Ensure this item is used in a Safe location.
- Incorrect Installation may result in instability and weakness
- Due to the weight of the item, maintain tightness of screws and bolts
- Keep Plastic Bags and Small Components away from Children
- Ensure Children do not jump on the table or seat top

PRODUCT NOTICE




- Your WPC Bench Set has been oiled at the factory
- Whilst WPC will not degrade in weather to the extent that wood will, like wood WPC is absorbent
- Therefore to minimising staining, the Bench Set SHOULD BE OILED FREQUENTLY (linseed oil is non-toxic and is recommended)
- WPC is more brittle than wood and should not be overly impacted

SAFETY FEATURES



- This Bench Set is extra heavy and is less likely to tip over or be upturned in heavy winds
- WPC is far more durable in weather and therefore less likely to splinter





IMPORTANT
WARNINGS
ON BACK




ASSEMBLY LEVEL






1.



2.



3.

